

GARR TOOL Milling Guide for V5 Series End Mills

(CHIP THINNING CALCULATION ALREADY APPLIED)

Fractional


	Material Group S	Material Group M	Material Group S	Material Group P	Material Group K
	Nickel or Cobalt-based	Stainless	Titanium Alloys	Carbon Steels	Grey Cast Iron
	Inconel, Cobalt Chrome	Invar, 400, 316, pH Series	6Al4V	1000 Series	
	SFM = 60 - 125	SFM = 150 - 300	SFM = 150 - 250	SFM = 300 - 500	SFM = 250 - 425
DIAMETER	CPT (Fz)	CPT (Fz)	CPT (Fz)	CPT (Fz)	CPT (Fz)
.2362"2755"	.0004"0008"	.0008"0012"	.0008"0011"	.0010"0012"	.0010"0012"
.2756"3124"	.0005"0010"	.0010"0018"	.0010"0015"	.0014"0028"	.0014"0028"
.3125"3749"	.0007"0012"	.0012"0020"	.0012"0018"	.0018"0031"	.0018"0031"
.3750"4999"	.0008"0015"	.0015"0022"	.0012"0021"	.0020"0035"	.0020"0035"
.5000"6249"	.0010"0018"	.0018"0030"	.0015"0025"	.0030"0041"	.0030"0041"
.6250"7499"	.0012"0020"	.0020"0033"	.0018"0030"	.0033"0043"	.0033"0043"
.7500"8749"	.0015"0022"	.0025"0037"	.0020"0032"	.0037"0045"	.0037"0045"
.8750" - 1.000"	.0018"0025"	.0030"0042"	.0025"0035"	.0041"0049"	.0041"0049"







	Nickel or Cobalt-based	Stainless	Titanium Alloys	Carbon Steels	Grey Cast Iron
	SFM = 100 - 200	SFM = 250 - 400	SFM = 300 - 500	SFM = 425 - 600	SFM = 325 - 500
DIAMETER	CPT (Fz)	CPT (Fz)	CPT (Fz)	CPT (Fz)	CPT (Fz)
.2362"2755"	.0007"0011"	.0011"0015"	.0011"0015"	.0016"0026"	.0016"0026"
.2756"3124"	.0008"0013"	.0015"0021"	.0013"0021"	.0018"0028"	.0018"0028"
.3125"3749"	.0010"0015"	.0018"0025"	.0015"0023"	.0020"0035"	.0020"0035"
.3750"4999"	.0011"0018"	.0021"0028"	.0018"0025"	.0030"0041"	.0030"0041"
.5000"6249"	.0013"0021"	.0023"0033"	.0021"0033"	.0033"0043"	.0033"0043"
.6250"7499"	.0015"0023"	.0028"0038"	.0023"0036"	.0037"0045"	.0037"0045"
.7500"8749"	.0018"0025"	.0033"0043"	.0028"0040"	.0041"0049"	.0041"0049"
.8750" - 1.000"	.0021"0028"	.0038"0048"	.0033"0045"	.0047"0059"	.0047"0059"





	Nickel or Cobalt-based	Stainless	Titanium Alloys	Carbon Steels	Grey Cast Iron
	SFM = 150 - 250	SFM = 300 - 500	SFM = 400 - 700	SFM = 500 - 700	SFM = 450 - 600
DIAMETER	CPT (Fz)	CPT (Fz)	CPT (Fz)	CPT (Fz)	CPT (Fz)
.2362"2755"	.0015"0020"	.0020"0025"	.0018"0022"	.0026"0033"	.0026"0033"
.2756"3124"	.0017"0022"	.0022"0030"	.0022"0028"	.0030"0041"	.0030"0041"
.3125"3749"	.0018"0025"	.0025"0035"	.0025"0032"	.0033"0043"	.0033"0043"
.3750"4999"	.0020"0028"	.0028"0040"	.0028"0035"	.0037"0045"	.0037"0045"
.5000"6249"	.0022"0030"	.0030"0045"	.0030"0040"	.0041"0049"	.0041"0049"
.6250"7499"	.0025"0032"	.0032"0050"	.0035"0045"	.0047"0059"	.0047"0059"
.7500"8749"	.0028"0035"	.0035"0055"	.0040"0050"	.0051"0063"	.0051"0063"
.8750" - 1.000"	.0032"0040"	.0040"0060"	.0045"0055"	.0055"0067"	.0055"0067"





GARR TOOL®

NOTE - ABOVE ARE STARTING PARAMETERS ONLY. HIGHER RESULTS MAY BE ACHIEVED WITH OPTIMUM CONDITIONS.